

Bilmärke	Modell	Typ	År	Filter
FORD	Mondeo III, 00-07	2.0-16V Di/TDDi Diesel Kombi	11.00-08.07	OL0124-E
FORD	Mondeo III, 00-07	2.0-16V Di/TDDi Diesel Kombi-sedan	11.00-08.07	OL0124-E
FORD	Mondeo III, 00-07	2.0-16V Di/TDDi Diesel Sedan	11.00-08.07	OL0124-E
FORD	Mondeo III, 00-07	2.0-16V TDCi Diesel Kombi	10.01-08.07	OL0124-E
FORD	Mondeo III, 00-07	2.0-16V TDCi Diesel Kombi-sedan	11.01-08.07	OL0124-E
FORD	Mondeo III, 00-07	2.0-16V TDCi Diesel Sedan	10.01-08.07	OL0124-E
FORD	Mondeo III, 00-07	2.0-16V TDDi/TDCi Diesel Kombi	11.00-08.07	OL0124-E
FORD	Mondeo III, 00-07	2.0-16V TDDi/TDCi Diesel Kombi-sedan	11.00-08.07	OL0124-E
FORD	Mondeo III, 00-07	2.0-16V TDDi/TDCi Diesel Sedan	11.00-08.07	OL0124-E
FORD	Mondeo III, 00-07	2.2 TDCi Diesel Kombi	09.04-08.07	OL0124-E
FORD	Mondeo III, 00-07	2.2 TDCi Diesel Kombi-sedan	09.04-08.07	OL0124-E
FORD	Mondeo III, 00-07	2.2 TDCi Diesel Sedan	09.04-08.07	OL0124-E
FORD	Transit, 00-06	2.0 Di Diesel Buss	08.00-05.06	OL0124-E
FORD	Transit, 00-06	2.0 Di Diesel Buss	08.00-05.06	OL0124-E
FORD	Transit, 00-06	2.0 Di Diesel Buss	08.00-05.06	OL0124-E
FORD	Transit, 00-06	2.0 Di Diesel Flak/Chassi	08.00-05.06	OL0124-E
FORD	Transit, 00-06	2.0 Di Diesel Flak/Chassi	08.00-05.06	OL0124-E
FORD	Transit, 00-06	2.0 Di Diesel Flak/Chassi	08.00-05.06	OL0124-E
FORD	Transit, 00-06	2.0 Di Diesel Skåp	08.00-05.06	OL0124-E
FORD	Transit, 00-06	2.0 Di Diesel Skåp	08.00-05.06	OL0124-E
FORD	Transit, 00-06	2.0 Di Diesel Skåp	08.00-05.06	OL0124-E
FORD	Transit, 00-06	2.0 TDCi Diesel Buss	08.02-05.06	OL0124-E
FORD	Transit, 00-06	2.0 TDCi Diesel Flak/Chassi	08.02-05.06	OL0124-E
FORD	Transit, 00-06	2.0 TDCi Diesel Skåp	08.02-05.06	OL0124-E
FORD	Transit, 00-06	2.4 Di Diesel Buss	01.00-05.06	OL0124-E
FORD	Transit, 00-06	2.4 Di Diesel Buss	01.00-05.06	OL0124-E
FORD	Transit, 00-06	2.4 Di Diesel Flak/Chassi	01.00-05.06	OL0124-E
FORD	Transit, 00-06	2.4 Di Diesel Flak/Chassi	01.00-05.06	OL0124-E
FORD	Transit, 00-06	2.4 Di Diesel Flak/Chassi	01.00-05.06	OL0124-E
FORD	Transit, 00-06	2.4 Di Diesel Skåp	01.00-05.06	OL0124-E
FORD	Transit, 00-06	2.4 Di Diesel Skåp	01.00-05.06	OL0124-E
FORD	Transit, 00-06	2.4 Di Diesel Skåp	01.00-05.06	OL0124-E
FORD	Transit, 00-06	2.4 TDCi Diesel Buss	03.04-05.06	OL0124-E
FORD	Transit, 00-06	2.4 TDCi Diesel Flak/Chassi	03.04-05.06	OL0124-E
FORD	Transit, 00-06	2.4 TDCi Diesel Skåp	03.04-05.06	OL0124-E
FORD	Transit, 00-06	2.4 TDdi Diesel Buss	10.01-03.06	OL0124-E
FORD	Transit, 00-06	2.4 TDE Diesel Buss	03.04-05.06	OL0124-E
FORD	Transit, 00-06	2.4 TDE Diesel Buss	07.01-05.06	OL0124-E
FORD	Transit, 00-06	2.4 TDE Diesel Flak/Chassi	03.04-05.06	OL0124-E
FORD	Transit, 00-06	2.4 TDE Diesel Flak/Chassi	07.01-05.06	OL0124-E
FORD	Transit, 00-06	2.4 TDE Diesel Skåp	03.04-05.06	OL0124-E
FORD	Transit, 00-06	2.4 TDE Diesel Skåp	07.01-05.06	OL0124-E
JAGUAR	X-Type	2.0 Diesel Kombi	02.04-	OL0124-E
JAGUAR	X-Type	2.0 Diesel Sedan	07.03-	OL0124-E
JAGUAR	X-Type	2.2 D Diesel Kombi	.2007-.2008	OL0124-E
JAGUAR	X-Type	2.2 D Diesel Kombi	.2009-.2010	OL0124-E
JAGUAR	X-Type	2.2 D Diesel Sedan	.2007-.2008	OL0124-E
JAGUAR	X-Type	2.2 D Diesel Sedan	.2009-.2010	OL0124-E
JAGUAR	X-Type	2.2 Diesel Kombi	10.05-	OL0124-E
JAGUAR	X-Type	2.2 Diesel Sedan	10.05-	OL0124-E